
dTV Middleware Server
dTV
SCP
IN Service
PSTN Exchange
Messaging Centre
Home
SMS
Send SMS to the home number
Display Messages
Set up call back